



Remove the lower nut on the belt tensioner bracket. Thread the 7/8" standoff onto the stud, and tighten (the standoff takes the place of the nut).



8.1L MERC