

TECHNICAL BULLETIN

EEC Keypad Sticker Removal & Installation

How to remove your old EEC control station keypad sticker and replace it with a new one.

STEP 1: USE A KNIFE BLADE TO REMOVE EXISTING KEYPAD STICKER

To remove the existing (old) keypad sticker, insert a knifeblade underneath the keypad sticker until the tip reaches the button impression. Pry up with knifeblade until edges release from control station.



STEP 2: REMOVE OLD KEYPAD STICKER AND PREPARE SURFACE

Grasp old keypad sticker and peel off control head. Clean adhesive residue on surface of control head with solvent (acetone). DO NOT use an excessive amount of solvent so that it seeps into the control head. Allow to dry before applying new keypad sticker.



STEP 3: APPLY NEW KEYPAD STICKER AND APPLY PRESSURE

Peel new keypad sticker away from release liner and position onto keypad depression along right-hand edge. Apply keypad sticker with pressure from fingertip.

